



# CBM Floppy 1541



CBM Floppy 1541  
IEC-Connector  
(male plug)



- 1 - SRQ - Serial Request In (NOT USED)
- 2 - GND - Ground
- 3 - ATN - Serial Attention In/Out
- 4 - CLK - Serial Clock In/Out
- 5 - DTA - Serial Data In/Out
- 6 - RST - Serial Reset

Interface  
CBM Floppy 1541 - R8C/13 - PC